


COBRA

DG350 ENGINE

OWNER'S MANUAL



CONTENTS

Introduction.....	3
Safety Messages.....	3
Safety Information.....	3
Parts Description.....	4
Before Operation Checks.....	4
Operation.....	5
Safe Operating Precautions.....	5
Starting the Engine.....	5
Stopping the Engine.....	6
Specifications.....	6
Servicing Your Engine.....	7
The Importance of Maintenance.....	7
Maintenance Safety.....	7
Safety Precautions.....	7
Maintenance Schedule.....	8
Refueling	8
Fuel Recommendations	8
Engine Oil.....	9
Air Cleaner	12
Spark Plug	13
Flywheel Brake Inspection	13
Engine Adjustments and Cleaning.....	14
Adding A Petrol Stabilizer to Extend Fuel Storage Life.....	15
Draining the Fuel Tank and Carburetor.....	15
Clean Fuel Strainer	16
Transporting	17
Taking Care of Unexpected Problems	17
Serial Number Location.....	18

INTRODUCTION



Thank you for purchasing the Cobra DG350 engine. In order to get the best results and fully understand how to operate it safely, please read these instructions carefully before attempting to use this engine.

Please keep the manual safe should you require it for future instruction.

Should you resell the lawnmower please do not forget to include this manual with the machine.

Please pay attention to the instruction manual provided with the equipment powered by this engine. Pay particular attention to safe engine start up/engine shut down, safe operation, adjustments and maintenance.


SAFETY MESSAGES

Please pay particular attention to this symbol , or . It is a warning sign, and features throughout this instruction manual. Failure to follow these warnings exactly can result in personal injury and even death to yourself or others. And injury to property.

SAFETY INFORMATION

- ▲ Fully understand how to operate all of the controls and learn how to stop the engine quickly and safely, in the case of an emergency. Before attempting to operate this equipment, make sure the user receives adequate instruction and training.
- ▲ This engine produces poisonous carbon monoxide from the exhaust. Never run the engine indoors and always ensure there is adequate ventilation.
- ▲ The engine and exhaust become very hot during operation. Keep the engine at least 3 feet (1 meter) away from buildings and other equipment during operation. Keep flammable materials away, and do not place anything on the engine while it is running.

PARTS DESCRIPTION



1. Starter grip
2. Fuel cap
3. Air filter
4. Primer bulb
5. Carburetor
6. Spark plug
7. Muffler/air filter
8. Oil filler cap/dipstick
9. Fuel tank

BEFORE OPERATION CHECKS

For your safety, and to maximize the service life of your equipment, it is very important to take a few moments to check the engine condition before operating. If a problem is detected do not run the engine before the required repair is carried out.

⚠ WARNING

Please ensure that proper maintenance is carried out on the engine. Failure to do so can result in a serious malfunction which can result in injury or even death. Always perform a pre-operation inspection before each operation and carry out the necessary repair.

Pre-operation check list;

Check the following items before you start the engine:

1. Fuel level
2. Oil level
3. Air filter
4. General inspection: Check for fluid leaks and loose or damaged parts
5. Check the equipment powered by this engine. And refer to the separate mower manual. Pay attention to any instructions “before use or set up”.

OPERATION

SAFE OPERATING PRECAUTIONS

Before operating the engine for the first time, please review the SAFETY INFORMATION section and the BEFORE OPERATION CHECKS above.

⚠ WARNING

Carbon monoxide gas is toxic. Breathing it can cause you to become unconscious and even kill you. Avoid any areas or actions that expose you to carbon monoxide


Never start this machinery indoors or where there isn't enough ventilation including your shed and garage. Carbon Monoxide can build up quickly and cause unconsciousness and death.

Pay attention to the instructions provided with the equipment powered by this engine for any safety precautions that should be observed with engine startup, shutdown, or operation.


STARTING THE ENGINE

A1. FOR STARTING A COLD ENGINE:

Press 3 times on the red Primer bulb. Close the lever of the safety brake (on the device). Pull the starter grip slowly until you feel resistance. Pull the cord rapidly to overcome the formation pressure of the recoil starter rope to start the engine.



⚠ If you push the primer bulb too often, there will be too much fuel in the carburetor and starting problems could arise.



A2. FOR STARTING A WARM ENGINE

When starting the engine from warm it may not be necessary to prime the engine.

⚠ The engine will stop if you release the brake control handle. Do not allow the starter grip to snap back against the engine. Return it gently to prevent damage to the starter and your hands.

STOPPING THE ENGINE

Release the brake control handle (located on the top handle) to stop the engine.

SPECIFICATIONS

Type	DG350
Total empty weight (kg)	9
Engine type	4-stroke,overhead valve, single cylinder
Displacement[Bore x Stroke]	99cc 56x40.2mm
Max. torque	4.5 N. m at 2800min ⁻¹
Cooling system	Forced air
Lubrication systems	Forced splash
Ignition system	CDI
PTO shaft rotation	Counterclockwise

ADJUSTMENT SPECIFICATIONS

ITEM	SPECIFICATION	MAINTENANCE
Spark plug gap	0.028-0.031 in(0.7-0.8mm)	Refer to page 13
Valve clearance (cold)	IN:0.10±0.02mm EX:0.12±0.02mm	See your authorized dealer
Other specifications	No other adjustments needed	

SERVICING YOUR ENGINE

THE IMPORTANCE OF MAINTENANCE

It is essential that good maintenance is carried out on this engine; it ensures safety and economical trouble free operation.

WARNING

Failure to carry out proper maintenance to correct a problem before operation can cause your engine to malfunction which can cause serious injury or even death. Always follow the inspection recommendations and schedules in this owner's manual.

In order for your engine to run safely and trouble free there is a maintenance schedule included in these instructions. Routine and simple maintenance procedures can be carried out with simple hand tools by you the user if you feel confident to do so. There are other service tasks that require specialist tools and are more difficult to carry out. These are best handled by a professional and we would recommend that they are performed by a qualified technician or mechanic. A list of service dealers can be found at www.cobragarden.co.uk or by calling 0115 986646.

Please pay attention to the maintenance schedule. Should you operate your engine under severe conditions such as unusual wet or dusty conditions or high load or high temperatures consult your servicing dealer to discuss your individual circumstances. In all other cases the maintenance schedule applies to normal operating conditions.

MAINTENANCE AND SAFETY

It is always recommended that more difficult maintenance and service to your engine is undertaken by a qualified technician preferably a Cobra service agent. Only you can decide if you can perform a given task. Service agents can be found at: www.cobragarden.co.uk

WARNING

Failure to properly follow maintenance instructions and precautions can result in injury or even death. Always follow the procedures and precautions in this owner's manual.

SAFETY PRECAUTIONS

Always ensure the engine is off and cooled down before carrying out maintenance or repairs.


This safe guards' and eliminates the following serious potential hazards;

 Carbon monoxide poisoning from engine exhaust.

Be sure there is adequate ventilation whenever you operate the engine.

 Burns from hot parts.

Always make sure the engine and exhaust system are cool before touching.

 Injury from moving parts.

Do not run the engine unless the instructions require you to do so.

⚠ WARNING

Make sure you fully read the instructions before you begin, and make sure you have the tools and skills required to carry out the maintenance/repair.

Always be cautious when working around petrol to reduce the possibility of fire or explosion.

Only use a nonflammable solvent, never petrol, to clean parts. Keep cigarettes, sparks and flames away from all fuel related parts.

Make sure worn or damaged parts are replaced for safety. Genuine parts should always be used as parts of inferior quality can damage the equipment and compromise safety

MAINTENANCE SHCHEDULE

REGULARSERVICE PERIOD(4)		Before Each Use	First Month or 5 Hrs	Every 3 Months or 25 Hrs	Every 6 Months or 50 Hrs	Every Year or 100 Hrs	Every Two Years or 250 Hrs	Page
ITEM								
Perform at every indicated month or operating hour interval. Whichever comes first								
Engine oil	Check	✓						9
	Refresh		✓		✓ 2			9
Air cleaner	Check	✓						12
	Clean			✓ 1				
	Replace						✓	
Spark plug	Check-adjust					✓		13
	Replace						✓	
Flywheel brake pad	Check				✓			13
Spark arrester	Clean					✓		13
Fuel tank and filter	Clean			✓		✓ 3		
Fuel tube	Check	Every 2 years (Replace if necessary) 3						
Valve clearance	Check-adjust					✓ 3		
Combustion Chamber	Clean	After every 200 hours 3						

(1) Service more frequently when used in dusty environments.

(2) Change the engine oil every 25 hours when used under heavy load or in high ambient temperatures.

(3) These items should be serviced by a Cobra authorized servicing dealer, unless you have the proper tools and are mechanically proficient.

If you fail to carry out the above maintenance schedule it could result in non warrantable failures.

REFUELING

Use unleaded Petrol with a pump octane rating of 86 or higher. This engine is certified to operate on unleaded petrol. Unleaded Petrol produces fewer engine and spark plug deposits and extends the exhaust system life.

Fill with fuel before mowing.

⚠ WARNING

Petrol is highly flammable and explosive, take care when refueling as you can burn or seriously injure yourself.

- ⚠ Stop engine and keep heat, sparks, and flame away. (never smoke when refueling)
- ⚠ Wait at least 15 minutes for the engine to cool
- ⚠ Refuel only outdoors.
- ⚠ Wipe up spills immediately.
- ⚠ If fuel is spilt on the machine or engine wipe up immediately and wait for vapors to dissipate before restarting.

⚠ WARNING

Fuel can damage and corrode some paint and some types of plastic. Always be careful not to spill fuel when re-fueling your fuel tank. Any damage caused by spilled fuel is not covered under the Warranty.


- ⚠ Always use the specified fuel. Never use stale or contaminated petrol or oil mixture. Avoid getting dirt or water in the fuel tank.

Adding Fuel

1. Carefully remove the fuel tank cap.
2. Fill the tank to the bottom of the fuel level limit in the neck of the fuel tank. Wipe up spilled fuel before starting the engine.

Never overfill.

Fuel tank capacity: (2.0L)



ENGINE OIL

Use 4-stroke motor oil that exceeds or meets the requirements for API service classification SH, SJ, or equivalent. Always check the API service label on the oil container to be sure it includes the letters SH, SJ, or

equivalent.


- ⚠ Always change the oil at the required service interval.(please refer to the maintenance schedule)

SAE 10W-30 is recommended for general use.

Oil Level Check

1. Check the oil with the engine **stopped and level**.

7.Oil filler cap/dipstick
Max:upper limit
Min :lower limit




2. Remove the oil filler cap/dipstick and wipe it clean with a clean rag to prevent dirt deposits contaminating fuel.
3. Insert the oil filler cap/dipstick into the oil filler neck as shown, but do not screw it in, then remove it to check the oil level.
4. If the oil level is near or below the lower limit mark on the dipstick, remove the oil filler cap/dipstick, and fill with the recommended oil to the upper limit mark (bottom edge of .the oil fill hole). Do not overfill.
5. Carefully replace the oil filler cap/dipstick.
6. Clean up any oil you may have spilled

- ⚠ This engine is delivered without oil, be sure to put oil in the engine before the starting. Use a clean, detergent and high quality oil SAE30 and API. SG, SH OR SJ classification.

Oil Change

- ⚠ Drain the engine oil when the engine is warm, warm oil drains quickly and completely.




7.Oil filler cap / dipstick
 A:Sealing washer
 B:Drain bolt

1. Place a suitable container next to the engine to catch the used oil.
2. Remove the drain bolt and drain the oil into the container by slightly tipping the engine toward the oil filler cap/dipstick. Please dispose of used motor oil in a manner that is compatible with the environment. We suggest you take used oil in a sealed container to your local recycling center for reclamation. Do not throw it in the bin or pour it on the ground or down a drain.
3. With the engine in a level position, re-fuel to the upper limit mark on the dipstick only use the recommended oil.
4. Replace the filler cap/dipstick carefully and securely.

⚠ Inferior oil can cause damage to your engine and affect engine warranty.

Volume of the oil tank:

0.105 US gal (0.4L)




← OIL FILLER CAP/ DIPSTICK

← UPPER LIMIT

← LOWER LIMIT

AIR CLEANER

- ⚠ It is essential that the air filter is clean and free from dirt and dust. If dirt is allowed to build up it will restrict air flow to the carburetor and cause poor engine performance and use up more fuel. Inspect the air filter before you operate the machine. If required clean the air filter. You will need to clean/change the air filter more frequently if you are operating the engine in very dusty and dry environments.
- ⚠ Never operate the engine without an air filter, or with a damaged air filter, as it will allow dirt to enter the engine, causing rapid engine wear. This type of damage is not covered under the warranty



Inspection

1. Remove the air filter cover. Be careful to prevent dirt and debris from falling into the air cleaner base.
2. Remove the air cleaner from the air filter base.
3. Inspect the air filter elements. Replace any damaged elements. Clean or replace dirty elements.

Cleaning

1. Remove the air filter cover and foam element, as described in the "INSPECTION" procedure.
2. Remove the foam element from the air cleaner base.
3. Tap the element several times on a hard surface to remove excess dirt. Never try to brush off dirt; brushing will force dirt into the fibers. Clean the foam element with water and detergent. Leave to fully air dry before reinstalling it.
4. Wipe dirt from the air filter base and cover using a moist rag. Be careful to prevent dirt from entering the air duct that leads to the carburetor.
5. Reinstall the air filter element, and make sure it is properly positioned. Install the air filter cover and tighten the two bolts securely.

SPARK PLUG

⚠ Always use the correct replacement spark plug as listed below.

Recommended Spark Plug: BPR5ES (NGK) The recommended spark plug is the correct heat range for normal engine operating temperatures.


⚠ WARNING

A loose spark plug can become very hot and can damage the engine. Over tightening the spark plug can damage the threads in the cylinder head.

Please be aware that incorrect spark plugs can cause engine damage.

Always ensure that the spark plug must be properly gapped and free of deposits.

1. Remove/disconnect the cap from the spark plug, clean and remove the dirt from around the plug and immediate area.
2. Ensure that the correct size spark plug wrench is used when removing the spark plug.
3. Inspect the spark plug. If the plug is worn or damaged, badly fouled, or if the sealing washer is in poor condition or if the electrode is worn replace with the correct spark plug.
4. It is important that the electrode gap is correct. Measure the electrode gap with a suitable gauge. The correct gap is 0.028 - 0.031 in (0.70 - 0.80 mm). If adjustment is needed, correct the gap by carefully bending the side electrode.



5. Be careful when installing the spark plug, by hand, to avoid cross-threading.
6. Ensure the correct size wrench is used when tightening the washer.
7. When installing a new spark plug, tighten 1/2 turn after the spark plug seats to compress the washer.
8. When reinstalling the original spark plug, tighten 1/8 1/4 turn after the spark plug seats to compress the washer.


FLYWHEEL BRAKE INSPECTION

1. Check to see if the inspection screw is contacting the brake bracket.
2. If the inspection screw is contacting to the brake bracket, take the engine to an authorized engine servicing

dealer for flywheel brake pad inspection.

3. Release the starter control handle (located on the equipment) and verify that there is a strong resistance when pulling on the recoil starter. Also verify that the governor arm is moved to the idle (slow), position and there is free play in the cable. The cable should be 10 to 15 mm from the centerline as shown when the cable is new.

4. Move the starter control handle (located on equipment) to release the flywheel brake, and verify that there is clearance between the governor arm and the throttle return rod when the throttles are in the fast (or high) position. Also verify that there is at least 2 mm clearance between the stopper and the brake cable bracket. (see page 6)



8. Fuel tank
A: Fly wheel
B: Brake system

ENGINE ADJUSTMENTS

⚠ WARNING

Do not change in any way the rated speed of the engine (carburetor side or regulator side).

Your engine was adjusted in the factory and the non-respect of the homologation speed engine could be dangerous for your safety and others safety. If the rated speed is changed in any way, the factory warranty will be cancelled.

Helpful tips and suggestions when storing your engine

Storage Preparation

Proper storage preparation is essential for keeping your engine trouble free and looking good. The following steps will help to keep rust and corrosion from impairing your engine's function and appearance, and will make the engine easier to start when you use it again.

Cleaning

If the engine has been running, allow it to cool for at least half an hour before cleaning. Clean all exterior surfaces, touch up any damaged paint, and coat other areas that may rust with a light film of oil.

⚠ WARNING

Using a garden hose or pressure washing equipment can force water into the air cleaner or muffler opening. Water in the air cleaner will soak the air filter, and water that passes through the air filter or muffler can enter the cylinder, causing damage.

Fuel

Petrol will oxidize and deteriorate in storage. Deteriorated fuel will cause hard starting, and it leaves gum deposits that clog the fuel system. If the petrol in your engine deteriorates during storage, you may need to have the carburetor, and other fuel system components, serviced or replaced. The air in a partially filled fuel tank promotes fuel deterioration. Very warm storage temperatures accelerate fuel deterioration. Fuel problems may occur within a few months, or even less if the petrol was not fresh when you filled the fuel tank.

Fuel system damage or engine performance problems resulting from neglected storage preparation are not covered under Warranty.

Adding a fuel stabilizer or additive to extend fuel storage life

When adding a petrol stabilizer, **fill** the fuel tank with fresh petrol. If only partially filled, air in the tank will promote fuel deterioration during storage. If you keep a container of petrol for refueling, be sure that it contains only fresh fuel.

1. Add the petrol stabilizer by following the manufacturer's instructions.
2. After adding a petrol stabilizer, run the engine outdoors for 10 minutes to be sure that treated fuel has replaced the untreated fuel in the carburetor.


Draining the fuel tank and carburetor warning**⚠ WARNING**

Petrol is highly flammable and explosive, and you can be burned or seriously injured when handling fuel. Stop the engine and keep heat, sparks, and flame away.

Refuel only outdoors.

Wipe up spills immediately.

1. Place an approved petrol container below the carburetor, and use a funnel to avoid spilling the fuel.
2. Remove the drain bolt, and then move the fuel valve lever to the ON position.
3. After all the fuel has drained into the container; reinstall the drain bolt and washer. Tighten the drain bolt securely.



Engine Oil


1. Change the engine oil (**see page 11**).
2. Remove the spark plug (**see page 13**).
3. Pour a tablespoon (5 - 10 cc) of clean engine oil into the cylinder.
4. Pull the recoil starter several times to distribute the oil.
5. Reinstall the spark plug.

Clean fuel strainer

⚠ WARNING

Petrol is extremely flammable and is explosive under certain conditions Do not smoke or allow flames or sparks in the area.

Remove the fuel strainer from the fuel tank and fuel line Clean the fuel strainer (remove dirt which has accumulated on the mesh, and check that the mesh is not broken anywhere). Reinstall the fuel strainer and fuel line.



A: Fuel strainer

Storage precautions


- ⚠** If you choose to store your engine with petrol in the fuel tank and in the carburetor, it is important to reduce the hazard of petrol vapor ignition. Only store your machine in a well ventilated indoor area. Store away from appliances that could cause a spark such as electric motors or where power tools are

Being operated. Do not locate your machine close to an open flame such as a heater/boiler. Always store your machine with the fuel valve in an “off” position.

Do not store your machine with high humidity as this can cause rust and corrosion.

Keep the engine level in storage. Tilting can cause fuel or oil leakage.

Removal from Storage

 Always fully check your machine before use. Check your engine as described in the “BEFORE OPERATION”

CHECKS section of this manual ([see page 4](#)).

If you drained your engine before storage, re-fuel using only fresh petrol. Do not use fuel stored in containers for long periods of time as petrol oxidizes and deteriorates which could cause difficulty when trying to start the engine.

If the cylinder was coated with oil during storage preparation, the engine will smoke briefly at startup. This is normal.

TRANSPORTING

 Always keep the machine level when transporting and make sure the fuel valve is in an “off” position.

TAKING CARE OF UNEXPECTED PROBLEMS


ENGINE WILL NOT START	Possible Cause	Correction
1. Check fuel.	Out of fuel.	Refuel
	Bad fuel; engine stored without eating or draining petrol, or refueled with bad petrol.	Drain the fuel tank and Carburetor (p. 9). Refuel With fresh petrol.
2. Remove and inspect Spark plug.	Spark plug faulty, fouled, or Improperly gapped. Spark plug wet with fuel (flooded engine).	Replace the spark plug(p. 13). Dry and reinstall spark plug.
3. Check choke	Choke is opened	Shut off choke well
4. Take engine to an authorized our Servicing dealer, or refer to shop manual	Fuel filter clogged, carburetor malfunction, ignition malfunction, valves stuck, etc.	Replace or repair faulty components as necessary.

ENGINE LACKS POWER	Possible Cause	Correction
1. Check air cleaner	Air cleaner elements clogged.	Clean or replace air Cleaner elements(p. 12)
2. Check fuel.	without treating or draining petrol, of refueled with bad petrol.	carburetor (p. 9). Refuel with fresh petrol.
3. Take engine to an authorized our servicing dealer, or refer to shop manual.	Fuel filter clogged, carburetor malfunction, ignition malfunction, valves stuck, etc	Replace or repair faulty Components as necessary.

TECHNICAL & CONSUMER INFORMATION

TECHNICAL INFORMATION

Serial Number Location



A:Serial number location

Record the engine serial number in the space below. You will need this information when ordering parts and when making technical or warranty inquiries.

Warranty: Please refer to mower manual for warranty.